

net2phone

Polycom Obihai Wi-Fi Setup



Requirements:

VVX Device must be on net2phone recommended firmware 5.9 or higher

Limitations:

- No other WiFi USB dongles are supported.
- VVX1500 not supported.
- New VVX250, VVX350 or VVX450 cannot use USB Headset concurrently at present.
- No WiFi and Ethernet at the same time.

Insert the Obihai Wi-Fi USB dongle into the USB port of your VVX phone.

The phone's screen prompts "A Wi-Fi Dongle is connected. Press Start to begin Wi-Fi setup."



Select Start.

Select Wi-Fi then select ON. The VVX phone will now reboot automatically.



After the phone has booted up, navigate to Settings → Basic → Wi-Fi to continue the Wi-Fi set up.

The phone will automatically scan for Wi-Fi networks and lists the available wireless networks. If the phone does not automatically scan, select Scan to manually initiate a Wi-Fi network scan. The phone automatically tries to connect to the saved wireless network, if any

Select a network in the scanned list and enter security information based on the network type to connect.

The phone connects to the wireless network based on the network type you have selected.